


陣屋ダム 一般周知立札



番号	立札間の距離(km)
1	0.3
2	0.6
3	0.4
4	0.2
5	0.6
6	0.4
7	0.1
8	0.5
9	1.1
10	0.2
11	0.9
12	0.5
13	0.1
14	0.1
15	0.2
16	0.7
17	0.4
18	0.5
19	0.3
20	1.0
21	0.7
22	0.6
23	0.3
24	0.4
25	0.0
26	1.0
27	1.2
28	0.1
29	0.6
30	0.8
31	0.1
32	0.7
33	0.7
34	0.4
35	0.4
36	0.3
37	0.8
38	0.4
39	0.5
40	0.7
41	0.2
42	0.5
43	0.3
44	0.4
45	0.3
46	0.8
47	0.4
48	0.6

番号	立札間の距離(km)
1	0.5
2	3.2
3	2.4



警報板 □

警報板(子供用) □